INSTALLATION INSTRUCTIONS

FOR ITEM 227866 GASCONY LANTERN PENDANT

Meyda
C U S T O M   L I G H T I N G

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician.
This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*
Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS
1. CANOPY ASSEMBLY
2. 144" CHAIN
3. LANTERN
4. 240" ANTI-SWAY CHAIN (QTY 4)
5. ANTI-SWAY WALL MOUNT HARDWARE (QTY 4)

Caution:
Fixture is OVERWEIGHT and not suitable for installation with standard Junction Box.
Be sure power is off at the main breaker box prior to installation.
Read all instructions in their entirety before beginning installation.

1. Carefully unpack all components and make certain that everything is accounted for.
2. Remove Screw Collar from Canopy Assembly to release Mounting Crossbar with Loop.
3. Affix Crossbar to ceiling ensuring that connection is suitable to hold a minimum of 75lbs and that Electrical Supply Wires remain accessible.
4. Attach desired length of Chain to Loop on top of Lantern using Quick Link.
5. Weave Lantern Lead Wire and Safety Cable through every 4th Link of Chain.
6. Slide Screw Collar and Canopy over Chain, Wire, and Cable and allow them to rest on top of Lantern.
7. Hang Fixture by attaching loose end of Chain to Crossbar Loop using Quick Link.
8. Feed Safety Cable through Channel in Crossbar Loop and attach to secure location in the ceiling ensuring that connection is suitable to hold a minimum of 75lbs.
9. Feed Lead Wires through Crossbar Loop and, Following all Local Codes and Procedures, make electrical connection from Fixture Lead Wires to Supply Wires.
10. Slide Canopy up Chain to ceiling and secure by threading Screw Collar onto Crossbar Loop.
11. Attach Anti-sway Wall Mount Hardware to desired locations.
12. Attach necessary lengths of Chain to Loops on Lantern using Quick Links.
13. Run Chains to Wall Mount Hardware and attach using Quick Links.
14. Unscrew and remove Knob to open Lantern Door.
15. Install 6 Candelabra Base 60Watt Bulbs(not included) into Sockets.
16. Close Door and screw Knob onto Stud to secure.
17. Power on and ENJOY!!!

CANOPY ASSEMBLY — CANOPY — CROSSBAR — SCREW COLLAR — BRASS LOOP

Ø 6"

144" CHAIN — CANOPY ASSEMBLY

ANTI-SWAY WALL MOUNT HARDWARE — LANTERN

ANTI-SWAY CHAIN

DOOR KNOB