

INSTALLATION INSTRUCTIONS

FOR ITEM 227906 LE PRINTEMPS 15 LIGHT CHANDELIER

Meyda
CUSTOM LIGHTING

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS

1. CANOPY ASSEMBLY
2. CHAIN (60")
3. CHANDELIER BODY
4. CANDLE COVER (QTY 15)

Caution:

Fixture is OVERWEIGHT and not suitable for installation with standard Junction Box.
Be sure power is off at the main breaker box prior to installation.
Read all instructions in their entirety before beginning installation.

1. Carefully remove wrap from Chandelier Body and all components.
Make certain that everything is accounted for.
2. Remove Screw Collar from Canopy Assembly to release Mounting Crossbar.
3. Affix Crossbar to ceiling ensuring that connection is suitable to hold a minimum of 100lbs and that Electrical Supply Wires remain accessible.
4. Unravel Lead Wires and Safety Cable from top of Chandelier Body and attach desired length of Chain to Quick Link.
5. Weave Wires and Cable through every 5th Link of Chain.
6. Slide Screw Collar and Canopy over Wires, Cable, & Chain and allow them to rest on top of Chandelier Body.
7. Hang Fixture from Crossbar Loop by connection loose end of Chain to Quick Link.
8. Feed Safety Cable through Channel in Crossbar Loop and attach it to a secure location in ceiling.
Ensure that connection is suitable to hold a minimum of 100lbs.
9. Slide Canopy and Screw Collar up Chain and feed Fixture Lead Wire through satellite hole in Canopy.
10. Following all Local Codes and Procedures, make electrical connection from Fixture Lead Wires to Supply Wires.
11. Lift Canopy up to ceiling allowing Crossbar Loop to pass through. Secure Canopy by threading Screw Collar onto Crossbar Loop.
12. Slide Candle Covers onto Sockets.
13. Install 15 Candelabra 60Watt Bulbs(not included) into Sockets.
14. Power on and ENJOY!!!

