

INSTALLATION INSTRUCTIONS

FOR ITEM 233629 (28" Wide Winter Pine 3 Light Vanity)

Meyda
CUSTOM LIGHTING

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician.

This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS

1. HANGER
2. SHADE
3. MOUNTING PLATE W/STUDS

Caution:

**Be sure power is off at the main breaker box prior to installation.
Read all instructions in their entirety before beginning installation.**

1. Carefully unpack all components and make certain that everything is on hand.
2. Unscrew Brass Knobs on Backplate to release the Mounting Plate with Studs (Save it for later).
3. Using Customer Supplied Hardware, affix Mounting Plate directly to J-box ensuring connection is suitable for a minimum of 20 lbs. and that electrical supply wires remain accessible.
4. Following all local codes and procedures unravel the wire on the back of the Backplate and make electrical wire connections from supply wire to fixture lead wires.
5. Secure Backplate to Mounting plate using the Brass Knobs from before.
6. Install 3X 60W E26 A19 Bulbs (not included) into socket.
7. Install shades on the hanger using Knurled Thumb Screw.
8. Power on and ENJOY!!!

