

INSTALLATION INSTRUCTIONS

FOR ITEM 240365 LANTERN WALL SCONCE

Meyda
CUSTOM LIGHTING

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS

1. ASSEMBLED SCONCE HARDWARE
2. 6"W x 15"H GLASS PANEL (QTY 2)
3. 3.5"W x 15"H GLASS PANEL (QTY 2)

Caution:

***Be sure power is off at the main breaker box prior to installation.
Read all instructions in their entirety before beginning installation.***

1. Carefully unpack all components and make certain that everything is accounted for.
2. Unravel Lead Wires from back of Sconce and separate Shade Frame from Wall Hanger carefully pulling Lead Wires through.
3. Remove Button Head Screws from sides of Wall Hanger to release Mounting Plate. Reserve Screws for later use.
4. Affix Mounting Plate to Junction Box ensuring that connection is suitable to hold a minimum of 15lbs and that Electrical Supply Wires remain accessible.
5. Unscrew Loop from top of Shade Frame and remove it and Roof Cap.
6. Using a 5/16" Nut Driver remove 4 Hex Nuts from Inner Corners of Shade Roof. Reserve Nuts.
7. Remove Shade Roof with Light Cluster and set aside.
8. Lie Shade Frame down and install 6"W Glass Panels. Panel should be held at an angle and inserted into Shade Frame. Once Panel is fully inside Frame, straighten and slide into Top Channel and then lower into Bottom Channel. Repeat this process for other 6"W Panel.
9. Follow Step 8 method to install 3.5"W Side Panels.
10. Stand Frame Up with Studs on top.
11. Carefully lower Light Cluster into Shade Frame and set Roof on top allowing Studs to protrude through.
12. Secure with reserved Hex Nuts.
13. Replace Roof Cap and Thread Loop onto exposed Nipple.
14. Feed Lead Wire through Pipe in Wall Hanger and Hang Shade from Hanger Hook.
15. Following All Local Codes and Procedures, make Electrical connection Sconce Lead Wires to Supply Wires.
16. Lift Wall Hanger up to Mounting Plate and secure with reserved Button Head Screws.
17. Install 2 Candelabra Base 60Watt Bulbs into Sockets.
18. Power on and ENJOY!!!

