

# INSTALLATION INSTRUCTIONS

FOR ITEM 250478 JEFFERSON PENDANT

*Meyda*  
CUSTOM LIGHTING

**CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE.** We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.\*

**Caution:** Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

## FIXTURE COMPONENTS

1. CANOPY ASSEMBLY w/ 2 ARMS
2. ARM
3. PENDANT BODY

### Caution:

**Fixture is OVERWEIGHT and not suitable for installation with standard Junction Box. Be sure power is off at the main breaker box prior to installation. Read all instructions in their entirety before beginning installation.**

1. Carefully unpack all components and make certain that everything is accounted for.

**\*\*Do Not Remove protective material from Pendant Body until installation is completed.\*\***

2. Remove Acorn and Hex Nuts from Canopy Assembly to release Mounting Plate. Reserve Nuts for later use.

3. Affix Mounting Plate to ceiling ensuring that connection is suitable to hold a minimum of 100lbs and that Electrical Supply Wires and Dimmer Wires remain accessible.

4. Lift Canopy Assembly w/ Arms up to ceiling allowing Mounting Plate Studs to pass through. Secure with reserved Hex and Acorn Nuts.

5. Remove Knurled Cap from center of Canopy to release Cover Plate.

6. Following all Local Codes and Procedures, make electrical connection from Fixture Lead Wires to Supply Wires.

7. If Fixture Dimming is desired, connect compatible 0-10V Dimmer Switch Wires to Fixture Dimming Wires.

Purple Fixture Wire will connect to Positive(+) Wire from Switch and Grey Fixture Wire will connect to Negative(-) Wire from Switch.

8. Replace Cover Plate and secure with Knurled Cap.

9. Attach Arm to vacant Loop on Canopy.

10. Hang Pendant Body from Arms ensuring to align Wired Arms with Wired Loops on Body.

Three-Prong Plug on Arm will align with Three-Prong Receptacle at Loop. Two-Prong Plug on Arm will align with Two-Prong Receptacle at Loop. Make Wired Connections.

11. Remove protective material from Pendant Body.

12. Power on and ENJOY!!!

