

INSTALLATION INSTRUCTIONS

FOR ITEM 252947 WESLEYAN WALL SCONCE



CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS

1. SCONCE HARDWARE
2. GLASS PANEL (QTY 8)

Caution:

Fixture is OVERWEIGHT and not suitable for installation with standard Junction Box. Be sure power is off at the main breaker box prior to installation. Read all instructions in their entirety before beginning installation.

1. Carefully unpack all components and make certain that everything is accounted for.
2. Remove Knobs from Sconce Hardware Backplate to release Mounting Plate.
3. Affix Mounting Plate to wall ensuring that connection is suitable to hold a minimum of 60lbs and that Electrical Supply Wires remain accessible.
4. Following all Local Codes and Procedures, make connection from Fixture Lead Wires to Supply Wires.
5. Hang Sconce Hardware by sliding Backplate over Mounting Plate Studs and secure with Knobs.
6. Unscrew Knobs at bottom of Shade to remove Finial.
7. Install Glass Panels into Shade Channels.
8. Install 1-E26 60Watt Bulb into Socket.
9. Replace Finial and secure with Knobs.
10. Power on and ENJOY!!!

