## INSTALLATION INSTRUCTIONS

FOR ITEM 252970 STAFFORD LANTERN WALL SCONCE



CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician.

This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.\*

**Caution**: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

## Caution:

Fixture is OVERWEIGHT and not suitable for installation with standard Junction Box.

Be sure power is off at the main breaker box prior to installation.

Read all instructions in their entirety before beginning installation.

- 1. Carefully unpack all components and make certain that everything is accounted for.
- 2. Remove Hex and Acorn Nuts from Backplate to release Mounting Plate and Pan.
- 3. Affix Mounting Plate to wall ensuring that connection is suitable to hold a minimum of 30lbs and that Electrical Supply Wires remain accessible.
- 4. Feed Fixture Lead Wires through hole in Pan and Following All Local Codes and Procedures, make connection from Fixture Lead Wires to Supply Wires.
- 5. Slide Pan and then Sconce Backplate onto Mounting Plate Studs and secure with Hex and Acorn Nuts.
- 6. Open Shade Door and install 1-E26 60Watt Bulb into Socket and close Door.
- 7. Power on and ENJOY!!!

