

# INSTALLATION INSTRUCTIONS

FOR ITEM (27" Wide Sonoma Inverted Pendant)



**CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE.** We recommend installation by a licensed electrician.

This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.\*

**Caution:** Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

## FIXTURE COMPONENTS

1. CANOPY ASSEMBLY (CANOPY, CROSSBAR, LOOP AND COLLAR, )
2. CHAIN
3. QUICK LINK- QTY 2
4. PENDANT HANGER (HUB, ARMS, LIGHT CLUSTER)
5. SHADE

### ***Caution:***

***Be sure power is off at the main breaker box prior to installation.  
Read all instructions in their entirety before beginning installation.***

1. Carefully unpack all components and make certain that everything is on hand.
2. Unscrew the collar on the loop at the bottom of the Canopy and slide it down the chain with the canopy pan. (This will give access to the crossbar)
3. Attach one end of the Chain to the Canopy Loop with the Quick Link
4. Attach Pendant Hanger from Hub Loop to other end of the chain with other Quick Link.
5. Using Customer Supplied Hardware, affix Crossbar (with the Chain and Pendant Hanger attached) to Junction Box ensuring connection is suitable to hold a minimum of 35 lbs. and that Electrical Supply Wires remain accessible.
6. Weave Pendant Lead Wires through every 4th Link of Chain and then feed through Canopy Loop.
7. Pendant have 2 Lead Wires one for Top Light Cluster and other for Bottom Light Cluster.
8. Make two separate connections in order to control each cluster independently.
9. Pass one lead wire through Collar of Canopy Assembly, and other through Black Bushing on Canopy.
10. Following All Local Codes and Procedures, make connection from Pendant Lead Wires to Supply Wires.
11. Bring the Canopy and Collar back up to the ceiling and secure in place by screwing the Collar back onto the Loop.
12. Install 4 X 60W E26 A19 and 4 X 50W E26 MR16 Bulbs (not included) into sockets.
13. Install shade on the Arms of the Pendant Hanger.
14. Power On and ENJOY!!!

# INSTALLATION INSTRUCTIONS

FOR ITEM 253867 (27" Wide Sonoma Inverted Pendant)

*Meyda*  
CUSTOM LIGHTING

**CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE.** We recommend installation by a licensed electrician.

This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.\*

**Caution:** Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

