

INSTALLATION INSTRUCTIONS

FOR ITEM 255745 BRUM WALL SCONCE

Meyda
CUSTOM LIGHTING

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

Caution:

***Be sure power is off at the main breaker box prior to installation.
Read all instructions in their entirety before beginning installation.***

1. Carefully unpack all components and make certain that everything is accounted for.
2. Remove Screws from sides of Sconce to separate Shade. Reserve Screws.
3. Remove Balls from Backplate to release Crossbar with Studs. Reserve Balls.
4. Using Customer Supplied Fasteners, attach Crossbar to Junction Box ensuring that connection is suitable to hold 10lbs and that Electrical Supply Wires remain accessible.
5. Following All Local Codes and Procedures, make connection from Fixture Lead Wires to Supply Wires.
6. Slide Backplate onto Crossbar Studs and secure with reserved Balls.
7. Install two E12 60Watt Bulbs(not included) into Sockets.
8. Move Shade into position over Backplate and secure with reserved Screws.
9. Power on and ENJOY!!!

