

# INSTALLATION INSTRUCTIONS

FOR ITEM 256320 PALOMA GOLPE CHANDEL-AIR

*Meyda*  
CUSTOM LIGHTING

**CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE.** We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.\*

**Caution:** Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

## FIXTURE COMPONENTS

1. CANOPY ASSEMBLY
2. DOWN ROD
3. 48"W CHANDEL-AIR BODY

### **Caution:**

**Fixture is OVERWEIGHT and not suitable for installation with standard Junction Box. Be sure power is off at the main breaker box prior to installation. Read all instructions in their entirety before beginning installation.**

1. Carefully unpack all components and make certain that everything is accounted for.
2. Affix Fixture Mounting Plate with Saddle to blocking ensuring that connection is suitable to hold a minimum of 100lbs and that Electrical Supply Wires remain accessible.
3. Unravel Fixture Lead Wires from top of Chandel-Air Body and feed through Rod.
4. Attach Down Rod Flange to top of Chandel-Air Body and secure with Hex and Acorn Nuts.
5. Slide Canopy over Down Rod and allow to rest on top of Chandel-Air Body.
6. Slide Half Steel Ball over Down Rod. Insert Spring Pin through channel at top of Down Rod. Lift Half Ball up to Pin and allow it to seat in channel.
7. Lift Fixture up to Mounting Plate and seat Half Steel Ball in Mounting Plate Saddle.
8. Following all Local Codes and Procedures, make connection from Fixture Lead Wires to Supply Wires.
9. Slide Canopy up Rod and secure to Mounting Plate Studs using Canopy Hardware.
10. Install 6-E26 20Watt LED PAR38 Short Neck Bulbs(not included) into Downlight Sockets. Install 6-E26 20Watt LED PAR30 Short Neck Bulbs(not included) into Uplight Sockets.
11. Power on and ENJOY!!!

