

INSTALLATION INSTRUCTIONS

FOR ITEM 267494 TYPE CK

Meyda
CUSTOM LIGHTING

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS

1. CANOPY ASSEMBLY
2. COUPLING ASSEMBLY
3. DECORATIVE COMPONENT
4. SLEEVE
5. CHECK RING
6. SHADE
7. SOCKET ASSEMBLY

Caution:

**Be sure power is off at the main breaker box prior to installation.
Read all instructions in their entirety before beginning installation.**

1. Carefully unpack all components and make certain that everything is accounted for.
2. Feed Lead Wire and Threaded Rod from Socket Assembly through Shade.
3. Slide Check Ring and Sleeve over Wire and Threaded Rod.
4. Feed Lead Wire through Decorative Component and rest it on Shade.
5. Feed Lead Wire through Coupling Assembly and add a drop of Loctite into both ends.
6. Seat Coupling Assembly squarely into Decorative Component.
7. Twist Socket Assembly to screw Threaded Rod into Coupling Assembly until tight.
8. Feed Lead Wire through Pipe on Canopy Assembly.
9. Screw Threaded end of Canopy Assembly into Coupling Assembly.
10. Remove Canopy Screws to separate Mounting Plate.
11. Attach Mounting Plate to Junction Box ensuring that connection is suitable to hold a minimum of 20lbs and that Electrical Supply Wires remain accessible.
12. Following All Local Codes and Procedures, make connection from Lead Wires to Supply Wires.
13. Lift Fixture to allow Canopy to engage Mounting Plate ensuring that Tabs align with Holes. Secure with Canopy Screws.
14. Install 1-E26 60Watt Bulb(not included) into Socket.
15. Power on and ENJOY!!!

