

INSTALLATION INSTRUCTIONS

FOR ITEM 269297 24"W OVERLOOK LOG ROOM SCONCE @ PORCH

Meyda
CUSTOM LIGHTING

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician.

This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS

1. CANOPY ASSEMBLY
2. 27" OF CHAIN
3. SCONCE BODY

Caution:

***Be sure power is off at the main breaker box prior to installation.
Read all instructions in their entirety before beginning installation.***

1. Carefully unpack all components and make certain that everything is accounted for.
2. Unscrew Set Screw from Canopy Cover and slide it down on Canopy Assembly. Reserve Set Screw for later use.
3. Mount Crossbar to secure location ensuring that connection is suitable to hold a minimum of 35lbs and that Electrical Supply Wires remain accessible.
7. Unravel Fixture Lead Wire from top of Sconce Body and attach desired length of Chain to Quick Link.
8. Weave Fixture Lead Wire through every 5th Link of Chain.
10. Hang Fixture Body by attaching loose end of Chain to Quick Link on Canopy Loop.
11. Feed Fixture Lead Wire through canopy and following all Local Codes and Procedures make electrical connection to Supply Wires.
12. Slide Canopy Cover up until top of Canopy Cover flush with ceiling. Secure Canopy Cover with Set Screw.
13. Slide Candle Covers over Sockets.
14. Install 8 Candelabra Base 40Watt Bulbs(not included) into Sockets.
15. Power on and ENJOY!!!

