

INSTALLATION INSTRUCTIONS

FOR VICTORIAN 2LT WALL SCONCE 27061

Meyda
CUSTOM LIGHTING

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS

1. 2LT WALL SCONCE HARDWARE
2. ROLLED EDGE CROSSBAR WITH ATTACHED STUDS
3. UNIVERSAL CROSSBAR
4. 8-30 SCREWS (QTY 2)

Caution: Be sure power is off at the main breaker box prior to installation. Read all instructions in their entirety before beginning installation.

1. Carefully unpack all components and make certain that everything is accounted for.
2. Remove Cap Nuts from face of Sconce Hardware to detach Rolled-Edge Crossbar from rear.
3. Attch Universal Crossbar to J-Box pulling lead wires through center hole in Crossbar.
4. Attach Rolled-Edge Crossbar with studs to center-top and bottom holes in Universal Crossbar using included 8-30 Screws. Ensure to pull lead wires through center hole. Tighten Hex Nuts on Crossbar Studs to make certain Studs will align with holes on Sconce Hardware.
5. Wire fixture to lead wires following all local codes and procedures.
6. Slide Sconce Hardware onto Crossbar Studs and secure with Cap Nuts.
7. Install 2 Medium Base 60Watt Bulbs(not included).

