

INSTALLATION INSTRUCTIONS

FOR ITEM 275508 (M91/FM-A & TR897-08R-1)

Meyda
CUSTOM LIGHTING

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician.

This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS

1. FITTER AND CANOPY
2. TR897-08R-1

Caution:

***Be sure power is off at the main breaker box prior to installation.
Read all instructions in their entirety before beginning installation.***

1. Carefully unpack all components and make certain that everything is on hand.
2. Release crossbar from Canopy by unscrewing the two Brass balls on the canopy.
3. Using customer supplied hardware, affix crossbar directly to J-box ensuring that connection is suitable for a minimum of 10 lbs and that electrical supply wires remain accessible.
4. Unravel the lead wires from the Canopy and lift fixture up to ceiling.
5. Following all local codes and procedures, make electrical connection from supply wires to fixture lead wires.
6. Carefully insert the studs back into the Canopy and secure using the Brass knobs from earlier.
7. Secure TR897-08R-1 Shade with Cork washer & Uno ring.
8. Install 1X 9WATT max E26 A19 Bulb (not included) into socket.
9. Power on and ENJOY!!!

