

INSTALLATION INSTRUCTIONS

FOR ITEM 278098 6" WIDE SANDERSON 2 LIGHT WALL SCONCE

Meyda
CUSTOM LIGHTING

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician.

This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS

1. FRAME
2. M-PLATE
3. GLOBE

Caution:

***Be sure power is off at the main breaker box prior to installation.
Read all instructions in their entirety before beginning installation.***

1. Carefully unpack all components and make certain that everything is accounted for.
2. Unscrew M-plate from Frame. Reserve Screws for later use.
3. Unscrew Wiring Lid from frame. Reserve parts for later use.
4. Mount M-plate to wall ensuring that Electrical Supply Wires remain accessible.
5. Feed Fixture Lead Wire and Supply Wire through a wire access door.
6. Install fixture on M-plate. Secure with 8x screws.
7. Following all Local Codes and Procedures make electrical connection to Supply Wires.
8. Install Wiring Lid to Frame.
9. Install two E26 20W MAX Bulbs (not included) into Sockets.
10. Install Globes on Holders. Secure with supplied screws.
11. Power on and ENJOY!!!

