

INSTALLATION INSTRUCTIONS

FOR ITEM 283707 29"W CITADEL 4 LT PENDANT

Meyda
CUSTOM LIGHTING

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician.

This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS

- | | |
|---------------------------------------|---|
| 1. CANOPY ASSEMBLY | 5. 4-7/16"W X 19-3/4"H GLASS PANEL(QTY.4) |
| 2. 47" OF CHAIN | 6. CANDLE COVER (QTY.4) |
| 3. PENDANT BODY | 7. STEEL CORNER STRAP (QTY.8) |
| 4. 13-1/2"W X 23"H GLASS PANEL(QTY.4) | |

Caution:

Fixture is OVERWEIGHT and not suitable for installation with standard Junction Box.

Be sure power is off at the main breaker box prior to installation.

Read all instructions in their entirety before beginning installation.

1. Carefully unpack all components and make certain that everything is accounted for.
2. Unscrew Canopy Cover from Canopy Assembly to release M-plate with Loop. Reserve Acorn Nuts for later use.
3. Mount M-plate to secure location ensuring that connection is suitable to hold a minimum of 100lbs and that Electrical Supply Wires remain accessible.
4. Unscrew Acorn Nuts from inside corners of Pendant Body. Reserve all for later use.
5. Install Glass Panels by gently setting them into Pendant Body interior. Glass Panels can be temporarily held in place using painters tape.
6. Once 2 adjacent Panels have been moved into position, they can be secured using reserved Steel Corner Straps and Acorn Nuts.

Repeat until all Panels have been installed and secured.

7. Unravel Fixture Lead Wire from top of Pendant Body and attach desired length of Chain to Quick Link.

8. Weave Fixture Lead Wire through every 5th Link of Chain.

9. Slide Canopy Cover over Chain and let it rest on top of Pendant Body.

10. Hang Fixture Body by attaching loose end of Chain to Quick Link on Canopy Loop.

11. Feed Fixture Lead Wire through hole in M-plate and following all Local Codes and Procedures make electrical connection to Supply Wires.

12. Slide Canopy Cover up Chain until top of Canopy Cover flush with ceiling. Secure Canopy Cover with Acorn Nuts.

13. Slide Candle Covers over Sockets.

14. Install 4 Candelabra Base 40Watt Bulbs(not included) into Sockets.

15. Power on and ENJOY!!!

