

INSTALLATION INSTRUCTIONS

FOR ITEM 286410 14" WIDE AUSTIN 3 LIGHT SCONCE

Meyda
CUSTOM LIGHTING

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician.

This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS

1. BACK PLATE
2. SHADE FRAME

Caution:

***Be sure power is off at the main breaker box prior to installation.
Read all instructions in their entirety before beginning installation.***

1. Carefully unpack all components and make certain that everything is on hand.
2. Unscrew Screws from sides to release the Shade.
3. Unscrew Brass Balls from Backplate to release the Crossbar.
4. Using Customer Supplied Hardware, affix crossbar directly into J-box ensuring connection is suitable for a minimum of 15 lbs and that electrical supply wires remain accessible.
5. Unravel wire at the back of the Backplate.
6. Following all local codes and procedures, make electrical wire connections from supply wires to lead wires.
7. Re-attach Backplate to Crossbar using Brass Balls from before.
8. Install 3 x 40WATT E26 A19 Bulbs (not included) into sockets.
9. Re-attach Shade to Backplate using Screws from before.
10. Power on and ENJOY!!!

