

# INSTALLATION INSTRUCTIONS

FOR ITEM 50863 WILLOW JADESTONE MINI PENDANT

*Meyda*  
CUSTOM LIGHTING

**CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE.** We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.\*

**Caution:** Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

## FIXTURE COMPONENTS

1. FIXTURE HARDWARE
2. STAINED GLASS SHADE

### **Caution:**

***Be sure power is off at the main breaker box prior to installation.  
Read all instructions in their entirety before beginning installation.***

1. Carefully unpack all components and make certain that everything is accounted for.
2. Remove Acorn Nuts from Canopy to release Crossbar with Studs. Reserve Nuts for later use.
3. Affix Crossbar to Junction Box using Customer Supplied Fasteners ensuring that connection is suitable to hold a minimum of 5lbs and that Electrical Supply Wires remain accessible.
4. Fixture height can be configured using the provided Suspension Rods. If necessary unscrew Rod from Canopy Swivel, pull Lead Wire through Canopy and add/exchange Rods. Once satisfied, feed Lead Wire through Canopy and screw Rod into Canopy Swivel.
5. Following All Local Codes and Procedures, make connection from Fixture Lead Wires to Supply Wires.
6. Slide Canopy onto Crossbar Studs and secure with reserved Nuts.
7. Remove Uno Ring from Uno Socket and insert Shade into Fitter. Secure Shade by threading Uno Ring onto Uno Socket.
8. Install 1-E26 60Watt Bulb(not included) into Socket.
9. Power on and ENJOY!!!

