

# INSTALLATION INSTRUCTIONS

FOR ITEM 74006 GREENBRIAR OAK INVERTED PENDANT

*Meyda*  
CUSTOM LIGHTING

**CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE.** We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.\*

**Caution:** Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

## FIXTURE COMPONENTS

1. CANOPY ASSEMBLY
2. CHAIN
3. HUB W/ STEM & LIGHT CLUSTER
4. SUPPORT ARM (QTY4)
5. GLASS SHADE
6. SHADE FINIAL
7. OAK LEAVES (QTY 4)

### Caution:

***Be sure power is off at the main breaker box prior to installation.  
Read all instructions in their entirety before beginning installation.***

1. Carefully unpack all components and make certain that everything is accounted for.
2. Unscrew Collar from Canopy Assembly to release Crossbar with Loop.
3. Affix Crossbar to ceiling ensuring that connection is suitable to hold a minimum of 40lbs. and that electrical supply wires remain accessible.
4. Attach desired length of Chain to Quick Link on Hub.
5. Weave Fixture Lead Wires and Safety Cable through every 5th Link of Chain.
6. Feed Chain, Lead Wires, & Safety Cable through Screw Collar and Canopy and allow them to rest on top of Hub.
7. Hang Fixture Hardware by connecting loose end of Chain to Quick Link on Crossbar Loop.
8. Feed Safety Cable through Loop Channel and secure to structure ensuring that connection is suitable to hold a minimum of 40lbs.
9. Feed Fixture Lead Wires through Loop Channel. Following all Local Codes and Procedures, make Electrical Connection from Lead Wires to Supply Wires.
10. Slide Canopy up Chain to ceiling and secure by Threading Screw Collar onto Crossbar Loop.
11. Hang Support Arms from Loops on Hub.
12. Lift Glass Shade up to Fixture and hang from Support Arms.
13. Feed Threaded Rod from Shade Finial up through center hole in Shade and screw into bottom of Light Cluster.
14. Slide Oak Leaf Cluster onto exposed Threaded Rod and secure with Finial Knob.
15. Hang Oak Leaves off side of Glass Shade.
16. Install 6 Medium Base 60Watt Bulbs(not included) into Sockets.
17. Power on and ENJOY!!!

