

SCONCE BRACKET SHADE SUPPORT X CAP NUT SOCKET SOCKET SOCKET PRINTED WIRE 1.5" BOLT BLACK WHRE WIRE NUT 1. SCONCE MOUNTING BOLTS STRIPED WIRE

IMPORTANT

TURN OFF THE POWER AT THE MAIN FUSE OR CIRCUIT BREAKER BOX BEFORE STARTING INSTALLATION

CAREFULLY UNPACK AND IDENTIFY ALL PARTS BEFORE ASSEMBLY. BULBS ARE NOT INCLUDED

- 1. Install 1" sconce mounting bolt through back of crossbar as shown. FIG.A
- 2. Mount crossbar to elec. box as shown FIG.A
- 3. Attach wires from sconce bracket to elec. box wires with wire nuts as shown, attach striped wire to white wire from box and printed wire to black wire from box. FIG.A
- 4. Attach ground wire to green ground screw on crossbar. FIG.A
- 5. Slide sconce bracket over 1" sconce mounting bolt and attach. FIG.A
- 6. Attach shade to shade holder using (3) thumb screws. FIG.B
- 7. Hang shade holder to shade supports using sconce support bar. FIG.b



"A Commitment to Excellence in Lighting and Service"