INSTALLATION INSTRUCTIONS

FOR ITEM 98959 SONOMA INVERTED PENDANT



CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician.

This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS

- 1. CANOPY ASSEMBLY
- 2. 48" CHAIN
- 3. HUB W/LIGHT CLUSTER
- 4. SHADE ARMS
- 5. SHADE FRAME
- 6. SHADE

Caution:

Fixture is OVERWEIGHT and not suitable for installation with standard Junction Box. Be sure power is off at the main breaker box prior to installation. Read all instructions in their entirety before beginning installation.

- 1. Carefully unpack all components and make certain that everything is accounted for.
- 2. Remove Brass Balls from Canopy Assembly to release Universal Crossbar with Studs. Reserve Balls.
- 3. Affix Universal Crossbar to Junction Box ensuring that connection is suitable to hold a minimum of 40lbs and that Electrical Supply Wires remain accessible.
- 3. Run desired length of Chain from Hub Loop to Canopy Loop.
- 4. Feed Lead Wires through Chain and through Canopy Wireway.
- 5. Following All Local Codes and Procedures, make connection from Fixture Lead Wires to Supply Wires.
- 6. Slide Canopy onto Crossbar Studs and secure with reserved Brass Balls.
- 7. Set Shade into Shade Frame and attach Shade Arms to Shade Frame. FIG A
- 8. Connect loose ends of Shade Arms to Hub Hooks.
- 9. Install 6-E26 60Watt Bulbs(not included) into Sockets.
- 10. Power on and ENJOY!!!



