



# ASSEMBLY INSTRUCTIONS FOR #148112




## BOTTOM VIEW

LENS / COVER



## FRONT VIEW

WALL PLATE



## REAR VIEW


WALL PLATE

### **IMPORTANT**

TURN OFF THE POWER AT THE MAIN FUSE OR CIRCUIT BREAKER BOX BEFORE STARTING INSTALLATION

CAREFULLY UNPACK AND IDENTIFY ALL PARTS BEFORE ASSEMBLY.

- 1) REMOVE LENS / COVER (A) BY REMOVING SCREWS (B) FROM TOP & BOTTOM OF FIXTURE
- 2) UNSECURE WALL PLATE (C) BY REMOVING SCREWS (D)
- 3) REMOVE WIRE NUTS (F) FROM NON-RIGID LED LIGHT BAR FROM DRIVER LABELED "WHITE" (E).
- 4) REMOVE EXISTING NON-RIGID LED LIGHTING STRIPS (G) FROM FRONT OF WALL PLATE (C) AND REPLACE WITH NEW RIGID LED LIGHT BARS , SUPPLIED.
- 5) MAKE NEW ELECTRICAL CONNECTION WITH NEW WIRE NUT, PROVIDED.
- 6) MAKE NEW ELECTRICAL CONNECTION WATERPROOF BY ADDING SILICONE TO NEW WIRE NUT.
- 7) REPLACE WALL PLATE (C) TO WALL USING EXISTING SCREWS.
- 8) REPLACE LENS / COVER (B) TO WALL PLATE (C) USING EXISTING SCREWS.



*"A Commitment to Excellence in Lighting and Service"*

CALL OUR CUSTOMER SERVICE DEPARTMENT AT 1-800-222-4009

MONDAY - FRIDAY 8:00a.m - 6:00p.m ET

visit us on the web at [www.meyda.com](http://www.meyda.com)