

ASSEMBLY INSTRUCTIONS FOR # 122728 (S15505-1)



1. Wire fixture wire to jbox, place fixture wire through hole located near canopy loop in canopy.
 2. Mark canopy for for holes to attach canopy to ceiling blocking.
 3. Drill holes in canopy and attach canopy to blocking.
 4. Attach fixture chain quick links to canopy loops (4).
 5. Thread fixture wire through fixture chain (every third link recommended).
- Fixture rings are marked with a "T" for the top ring, a "↑" for the middle ring, and a "B" for the bottom ring.
6. Place the bottom ring on a flat surface.
 7. Connect main arms (main arms have curls on each end) to bottom ring. Main arms and rings are marked 1,3,5,&7. Attach in this order.
 8. Do not tighten, you will need play when placing middle ring to main arms.
 9. Place middle ring onto main arm ledges. Bolt together (do not tighten).
 10. Place top ring onto main arm ledges and bolt together. Tighten all bolts.
 11. Bolt support arms (flat) to ring holes marked 1,3,5,&7.
 12. Hang assembled fixture onto fixture chain rings.
 13. Place fixture wire down through loops located on side of support arm #7.
 14. Wire fixture wire to ring wire located at removed light socket, replace light socket.



"A Commitment to Excellence in Lighting and Service"

CALL OUR CUSTOMER SERVICE DEPARTMENT AT 1-800-222-4009

MONDAY - FRIDAY 8:00 a.m. - 6:00 p.m. ET

visit us on the web at www.meyda.com