INSTALLATION INSTRUCTIONS

FOR ITEM 133121 60" Wide Loxley 24 LT Two Tier Chandelier



CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician.

This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS

- 1. CANOPY ASSEMBLY
- 2. 120" CHAIN
- 3. 30"W TOP TIER
- 4. 60"W BOTTOM TIER
- 5. HUB W/ CHAINS & WIRES
- 6. CANDLE COVERS (QTY 24)

Caution:

Fixture is OVERWEIGHT and not suitable for installation with standard Junction Box. Be sure power is off at the main breaker box prior to installation. Read all instructions in their entirety before beginning installation.

- 1. Carefully unpack all components and make certain that everything is accounted for.
- 2. Unscrew Collar from Canopy Assembly to release Mounting Plate with Loop and Quick Link.
- 3. Affix Mounting Plate to ceiling ensuring that connection is suitable to hold a minimum of 100lbs and that Electrical Supply Wires remain accessible.
- 4. Attach the desired length of Chain to the Quick Link on the Hub.
- 5. Weave Fixture Lead Wires and Safety Cable through Chain.
- 6. Slide Screw Collar and Canopy over Wire, Cable, and Chain and allow them to rest on Hub.
- 7. Hang Hub by connecting loose end of Chain to Quick Link on Mounting Plate Loop.
- 8. Feed Safety Cable through Channel in Mounting Plate Loop and attach to secure location in ceiling ensuring that connection is suitable to hold a minimum of 100lbs.
- 9. Feed Fixture Lead Wires through Channel in Mounting Plate Loop and, Following all Local Codes and Procedures, make connection from Fixture Lead Wires to Supply Wires.
- 10. Slide Canopy and Screw Collar up Chain to ceiling. Secure Canopy by threading Screw Collar onto Mounting Plate Loop.
- 11. Attach 30"W Tier to Short Chains from Hub ensuring to align Chains with Short Wires with Electrical Receptacles on Tier. Make connections from Wires to Receptacles.
- 12. Attach 60"W Tier to Long Chains from Upper Tier ensuring to align Chains with Long Wires with Electrical Receptacles on Tier. Make connections from Wires to Receptacles.
- 13. Slide Candle Covers onto Sockets.
- 14. Install 24 Candelabra Base 60Watt Bulbs(not included) into Sockets.
- 15. Power on and ENJOY!!!

INSTALLATION INSTRUCTIONS

FOR ITEM 133121 60" Wide Loxley 24 LT Two Tier Chandelier



CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician.

This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS

- 1. CANOPY ASSEMBLY
- 2. 120" CHAIN
- 3. 30"W TOP TIER
- 4. 60"W BOTTOM TIER
- 5. HUB W/ CHAINS & WIRES
- 6. CANDLE COVERS (QTY 24)

Caution:

Fixture is OVERWEIGHT and not suitable for installation with standard Junction Box.

Be sure power is off at the main breaker box prior to installation.

Read all instructions in their entirety before beginning installation.



