


# ASSEMBLY INSTRUCTIONS FOR #202258-9-EB



## IMPORTANT


TURN OFF THE POWER AT THE MAIN FUSE OR CIRCUIT BREAKER BOX BEFORE STARTING INSTALLATION

CAREFULLY UNPACK AND IDENTIFY ALL PARTS BEFORE ASSEMBLY. BULBS ARE NOT INCLUDED



- 1.) Install top and bottom mounting brackets with secure fasteners (supplied by others)
- 2.) Install 26W CFL bulb
- 3.) Connect power supply per local codes see fig. A
- 4.) Plug red and white inverter wires together at connector (fig.A)
- 5.) Mount by placing lip of backing plate over top mounting bracket and sliding down.
- 6.) Screw mounting screw into mounting bracket

## I. ONE (1) FOUR PIN COMPACT LAMP RAPID START BALLAST

### 1.B) FLEX Conduit Wiring Diagram:



### 2.A) FLEX Conduit Wiring Diagram:



*"A Commitment to Excellence in Lighting and Service"*

CALL OUR CUSTOMER SERVICE DEPARTMENT AT 1-800-222-4009

MONDAY - FRIDAY 8:00a.m - 6:00p.m ET

visit us on the web at [www.meyda.com](http://www.meyda.com)