

INSTALLATION INSTRUCTIONS

FOR ITEM 162887 42" CAROUSEL INVERTED PENDANT

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician.

This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS

1. CANOPY ASSEMBLY
2. 36" OF CHAIN
3. PENDANT BODY

Caution:

***Be sure power is off at the main breaker box prior to installation.
Read all instructions in their entirety before beginning installation.***

1. Carefully unpack all components and make certain that everything is accounted for.
2. Remove Screw Collar from Canopy Assembly to release Crossbar with attached Loop and Quick Link.
3. Affix Crossbar to Junction Box using Customer Supplied Hardware.
Ensure that connection is suitable to hold a minimum of 50lbs and that Electrical Supply Wires remain accessible.
4. Unravel Fixture Lead Wires from top of Pendant Body and connect desired length of Chain to Quick Link.
5. Weave Lead Wires through every 5th Link of Chain.
6. Feed Chain through Screw Collar and center hole in Canopy.
7. Feed Lead Wires through hole in Canopy.
8. Hang Fixture by attaching loose end of Chain to Quick Link on Crossbar Loop.
9. Following all Local Codes and Procedures, make electrical connections from Fixture Lead Wires to Supply Wires.
11. Slide Canopy up to ceiling and secure by threading Collar onto Crossbar Loop.
12. Install 8 E26 40Watt Bulbs(not included) into Sockets.
13. Power on and ENJOY!!!

