
RE-LAMPING INSTRUCTIONS FOR # 166538



Fig.2 Knurled nut Coupling Top knots



IMPORTANT

TURN OFF THE POWER AT THE MAIN FUSE OR CIRCUIT BREAKER BOX BEFORE STARTING INSTALLATION

CAREFULLY UNPACK AND IDENTIFY ALL PARTS BEFORE ASSEMBLY. BULBS ARE NOT INCLUDED

- 1.)Unravel the wire holding your netting tight. (Fig.1)You do not need to take it completely off.(Fig.2)
- 2.)Unscrew your coupling and then your knurled nut. You do not need to unscrew your knurled nut completely off, (Fig.2) just enough to loosen the cap and plate. (Fig.3) 3.)Install your bulbs, provided by others.
- 4.)Replace your cap and plate. Tighten down the knurled nut and screw the coupling back down.
- 5.)Pull the wire and bunch the netting up onto the coupling.(Fig.2)
- 6.) Wrap the wire back around the bunched netting, and try to wrap it so that the wire wraps just under the top knots. (Fig. 2)



"A Commitment to Excellence in Lighting and Service"