

THIS FIXTURE WEIGHS OVER 50 LBS.

0700 01/11/16

NEC:314.27B, A luminaire that weighs more than 23kg (50lbs.) shall be supported independently of the outlet box unless the outlet box is listed AND MARKED for the MAXIMUM WEIGHT to be supported.


ASSEMBLY INSTRUCTIONS FOR #174864

IMPORTANT

TURN OFF THE POWER AT THE MAIN FUSE OR
CIRCUIT BREAKER BOX BEFORE STARTING
INSTALLATION

CAREFULLY UNPACK AND IDENTIFY ALL
PARTS BEFORE ASSEMBLY. BULBS ARE NOT
INCLUDED

- 1.) Attach crossbar to ceiling. There should be two bolts pointing down to receive canopy/fixture. (Fig.1)
- 2.) You may attach arms and fixture's oval before or after canopy is secure to ceiling.
- 3.) Raise canopy to ceiling and connect all electrical wires as per your local codes. Slide canopy up onto the two bolts pointing down from crossbar. Secure canopy flush to ceiling with two nuts provided. (Fig.1)
- 4.) Raise fixture oval to an arms length from hub. Run electrical wire from each arm through its corresponding loop. Hook arms onto loops once arm wires are through hub loops, be sure to not pinch wires. (Fig.2)
- 5.) Connect hub wires as per your local codes. You do not need to uncrimp the crimped nuts. (Fig.3)
- 6.) Once hub wires are connected screw your two nipples (Fig.4) into the two hickey's located inside the hub (Fig.3). Place hub cover up onto the hub and the two nipples should protrude a little through hub cover. Secure cover with the two hub nuts provided. (Fig.4)
- 7.) Execute step 3 if you have not already. Place candle covers, bulb your fixture (bulbs provided by others). Power on, enjoy your new fixture!



"A Commitment to Excellence in Lighting and Service"

CALL OUR CUSTOMER SERVICE DEPARTMENT AT 1-800-222-4009

MONDAY - FRIDAY 8:00a.m - 6:00p.m ET

visit us on the web at www.meyda.com