

THIS FIXTURE WEIGHS OVER 75 LBS.

0700 12/14/16

NEC:314.27B, A luminaire that weighs more than 23kg (50lbs.) shall be supported independently of the outlet box unless the outlet box is listed AND MARKED for the MAXIMUM WEIGHT to be supported.


ASSEMBLY INSTRUCTIONS FOR #181177

IMPORTANT

**TURN OFF THE POWER AT THE MAIN FUSE OR
CIRCUIT BREAKER BOX BEFORE STARTING
INSTALLATION**

**CAREFULLY UNPACK AND IDENTIFY ALL
PARTS BEFORE ASSEMBLY. BULBS ARE NOT
INCLUDED**

- 1.) Attach ceiling bracket to ceiling.**
- 2.) Bulb fixture, (bulbs provided by others).**
- 3.) Raise fixture to ceiling, connect electrical wires as per your local electrical code.**
- 4.) Slide fixture/canopy up onto the bracket bolts, and secure in place with canopy nuts.**
- 5.) Power on, enjoy your new breezy fixture!**



"A Commitment to Excellence in Lighting and Service"

CALL OUR CUSTOMER SERVICE DEPARTMENT AT 1-800-222-4009

MONDAY - FRIDAY 8:00a.m - 6:00p.m ET

visit us on the web at www.meyda.com