

THIS FIXTURE WEIGHS OVER 40 LBS.

0700 10/14/16

NEC:314.27B, A luminaire that weighs more than 23kg (50lbs.) shall be supported independently of the outlet box unless the outlet box is listed AND MARKED for the MAXIMUM WEIGHT to be supported.

ASSEMBLY INSTRUCTIONS FOR # 185870

IMPORTANT

**TURN OFF THE POWER AT THE MAIN FUSE OR
CIRCUIT BREAKER BOX BEFORE STARTING
INSTALLATION**

**CAREFULLY UNPACK AND IDENTIFY ALL
PARTS BEFORE ASSEMBLY. BULBS ARE NOT
INCLUDED**

- 1.) Attach your ceiling bracket to ceiling. Bring canopy (with fixture attached) to ceiling and connect electrical wires as per your local electrical code. Slide canopy up onto the bracket bolts. Secure canopy flush to ceiling by screwing the canopy nuts onto the bracket bolts.**
- 2.) Bulb your fixture, (bulbs provided by others). Power on, enjoy your new fixture!**


**Electrical
wires**

**Ceiling
bracket**

**Bracket
bolts**

Canopy

**Canopy
nuts**



"A Commitment to Excellence in Lighting and Service"

CALL OUR CUSTOMER SERVICE DEPARTMENT AT 1-800-222-4009

MONDAY - FRIDAY 8:00a.m - 6:00p.m ET

visit us on the web at www.meyda.com