INSTALLATION INSTRUCTIONS

FOR ITEM 212269 Antlers Moose 12 Light Chandelier



CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician.

This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS

- 1. CANOPY ASSEMBLY
- 2. 72" CHAIN
- 3. ANTLER CHANDELIER BODY

Caution:

Fixture is OVERWEIGHT and not suitable for installation with standard Junction Box. Be sure power is off at the main breaker box prior to installation. Read all instructions in their entirety before beginning installation.

- 1. Carefully unpack all components and make certain that everything is accounted for.
- 2. Remove Nuts from Canopy Assembly to release Mounting Plate with Loop, and Quick Link. Reserve Nuts.
- 3. Affix Mounting Plate to ceiling ensuring that connection is suitable to hold a minimum of 150lbs and that Electrical Supply Wires remain accessible.
- 4. Attach desired length of Chain to Loop on top of Antler Chandelier Body.
- 5. Weave Fixture Lead Wire through every 5th Link of Chain.
- 6. Slide Canopy over Chain and Wire and allow it to rest on top of Chandelier Body.
- 7. Hang Fixture by attaching loose end of Chain to Quick Link on Mounting Plate Loop.
- 8. Following All Local Codes and Procedures, make connection from Fixture Lead Wires to Supply Wires.
- 9. Slide Canopy up Chain allowing Mounting Plate Studs to pass through. Secure with reserved Nuts.
- 10. Install 12-E12 60Watt Bulbs(not included) into Sockets.

