

# INSTALLATION INSTRUCTIONS

FOR ITEM 229038 VELA CASCADING PENDANT



**CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE.** We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.\*  
**Caution:** Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

## FIXTURE COMPONENTS

1. CANOPY ASSEMBLY W/ SUPPORT CABLES
2. 70" EXTERIOR SHADE
3. 46" INTERIOR SHADE

### Caution:

**Fixture is OVERWEIGHT and not suitable for installation with standard Junction Box. Be sure power is off at the main breaker box prior to installation. Read all instructions in their entirety before beginning installation.**

1. Carefully unpack all components and make certain that everything is accounted for.
2. Remove Acorn Nuts from Canopy Assembly to release Mounting Plate. Reserve Nuts for later use.
3. Affix Mounting Plate to ceiling ensuring that connection is suitable to hold a minimum of 60lbs and that Electrical Supply Wires remain accessible.
4. Following all Local Codes and Procedures make electrical connection from Driver Lead Wires to Supply Wires.
5. If a Remote/Wall Mount Dimmer will be used, connect wiring from Dimmer to Dimmer Control Wires on Driver. A 0-10% Dimmer must be used for proper functionality.  
*Before moving on to the next step, make note of which Grippers on Canopy are receiving power from Drivers. White Wires from Drivers are marked as (-) and will serve as Negative Power sent to Shades. Black Wires from Drivers are marked as (+) and will serve as Positive Power sent to Shades.*
6. Once connections have been made, lift Canopy up to ceiling allowing Mounting Plate Studs to pass through and secure with reserved Acorn Nuts.
7. Hang 46" Interior Shade by running Support Cables from Inner Canopy Grippers to Grippers on Shade. Ensure to align Grippers marked (+) and (-) on Canopy with Grippers marked (+) and (-) on Shade. Set desired Cable length by loosening Nut at Top of Gripper and feeding Cable through. Push loosened Nut in and pull Cable to release. Once Cable length has been set, tighten Gripper Nuts. Once desired hanging orientations has been achieved, excess Cable can be cut.
8. Hang 70" Exterior Shade by running Support Cables from Outer Canopy Grippers to Grippers on Shade. Ensure to align Grippers marked (+) and (-) on Canopy with Grippers marked (+) and (-) on Shade. On the Canopy, the Outer-Right Gripper in each the (+) and (-) Gripper Cluster, should be powered. This should have been verified prior to step 6. Set desired Cable length by loosening Nut at Top of Gripper and feeding Cable through. Push loosened Nut in and pull Cable to release. Once Cable length has been set, tighten Gripper Nuts. Once desired hanging orientations has been achieved, excess Cable can be cut.
9. Power on and ENJOY!!!

