INSTALLATION INSTRUCTIONS

FOR ITEM 24264 HX4 CHANDELIER HARDWARE



CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician.

This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS

- 1. CANOPY ASSEMBLY
- 2. 36" CHAIN
- 3. CHANDELIER BODY

Caution:

Be sure power is off at the main breaker box prior to installation. Read all instructions in their entirety before beginning installation.

- 1. Carefully unpack all components and make certain that everything is accounted for.
- 2. Remove Acorn Nuts from Canopy Assembly to release Crossbar. Reserve Acorn Nuts for later use.
- 3. Using Customer Supplied Hardware, affix Crossbar to Junction Box ensuring that connection is suitable to hold a minimum of 15lbs and that Electrical Supply Wires remain accessible.
- 4. Attach desired length of Chain to Chandelier Body.
- 5. Attach loose end of Chain to Canopy.
- 6. Weave Fixture Lead Wires through every 3rd Link of Chain.
- 7. Feed Fixture Lead Wires through Channel in Canopy Loop.
- 8. Following all Local Codes and Procedures, make Electrical Connection from Fixture Lead Wires to Supply Wires.
- 9. Lift Canopy up to Ceiling allowing Crossbar Studs to protrude through. Secure Fixture with reserved Acorn Nuts.
- 10. Unscrew Uno Rings from Sockets and loosen Set Screws on Shade Caps.
- 11. Lift Shades up to Shade Caps and screw Uno Rings onto Sockets until tight. Tighten Set Screws to secure.
- 12. Install 4 Medium 60Watt Bulbs(not included) into Sockets.
- 13. Power on and ENJOY!!!



