INSTALLATION INSTRUCTIONS

FOR ITEM 284260 5" WIDE CLASSIC SWING ARM WALL SCONCE



CROSSBAR

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician.

This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS

- SCONCE ASSEMBLY
- 2. MS275-14R-1 SHADE


Caution:

Be sure power is off at the main breaker box prior to installation. Read all instructions in their entirety before beginning installation.

- 1. Carefully unpack all components and make certain that everything is accounted for.
- 2. Remove Brass Balls to release Crossbar with Studs. Reserve Balls for later use.
- 3. Using Customer Supplied Fasteners, affix Crossbar with Studs to Junction Box ensuring that connection is suitable to hold a minimum of 10lbs and that Electrical Supply Wires remain accessible.
- 4. Following All Local Codes and Procedures make connection from Fixture Lead Wires to Supply Wires.
- 5. Slide Sconce onto Crossbar Studs and secure with Brass Balls.
- 6. Secure MS275-14R-1 Shade to socket with Uno Ring & Cork Washer.

7. Install E26 A19 60Watt MAX Bulb(not included) into Sockets.

8. Power on and ENJOY!!!



MEYDA.COM 1.800,222,4009 SALES@MEYDA.COM