INSTALLATION INSTRUCTIONS

FOR ITEM 35748 (33" Long Deer at Lake Oblong Pendant)



CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL

INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS

- CANOPY ASSEMBLY
- 2. CHAIN (2X30")
- SHADE
- 4. CROSSBAR W/ STUDS

Caution:

Be sure power is off at the main breaker box prior to installation. Read all instructions in their entirety before beginning installation.

- 1. Carefully unpack all components and make certain that everything is accounted for.
- 2. Remove Brass Balls from Canopy Assembly to release Universal Crossbar. Reserve Brass Balls for later use.
- 3. Using Customer Supplied Hardware, affix Universal Crossbar to Junction Box ensuring connection is suitable to hold a minimum of 20lbs. and that Electrical Supply Wires remain accessible.
- 4. Attach desired length of Chain to Loops on Shade.
- 5. Attach loose ends of Chain to Loops on Canopy.
- 6. Weave Fixture Lead Wires through every 4th Link of Chain and then feed through Canopy Loop.
- 7. Following All Local Codes and Procedures make connection from Fixture Lead Wires to Supply Wires.
- 8. Lift Fixture up to ceiling allowing Crossbar Studs to pass through Canopy, Secure with reserved Brass Balls.
- 9. Install 6 X E26 60Watt Bulbs(not included) into Sockets.
- 10. Power on and ENJOY!!!

