INSTALLATION INSTRUCTIONS

FOR ITEM 38972 Stillwater Winter Pine Wall Sconce



CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL **INJURY OR DEATH AND PROPERTY DAMAGE.** We recommend installation by a licensed electrician.

This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.* **Caution**: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

Caution:

Be sure power is off at the main breaker box prior to installation. Read all instructions in their entirety before beginning installation.

- 1. Carefully unpack all components and make certain that everything is accounted for.
- 2. Unscrew Knurled Cap from interior of Wall Sconce to release Crossbar with Threaded Nipple. Reserve Cap for later use.
- 3. Using Customer Supplied Fasteners, affix Crossbar to Junction Box ensuring that connection is suitable to hold a minimum of 10lbs and that Electrical Supply Wires remain accessible.
- 4. Following All Local Codes and Procedures, make Electrical Connection from Fixture Lead Wires to Supply
- 5. Slide Sconce onto Threaded Nipple and secure by screwing Knurled Cap onto Nipple inside of Sconce until Cap it tight to Backplate.
- 6. Install Medium Base 60Watt Bulb(not included) into Socket.
- 7. Power on and ENJOY!!!

