

INSTALLATION INSTRUCTIONS

FOR ITEM 245501 & 248522

Meyda
CUSTOM LIGHTING

CAUTION: FAILURE TO INSTALL THIS FIXTURE PROPERLY MAY RESULT IN SERIOUS PERSONAL INJURY OR DEATH AND PROPERTY DAMAGE. We recommend installation by a licensed electrician. This product must be installed in accordance with applicable installation code(s), by a person familiar with the construction and operation of the product and the hazards involved.*

Caution: Do not exceed maximum wattage noted on fixture. Use only recommended bulbs with fixture.

FIXTURE COMPONENTS

- | | |
|---------------------------------------|-----------------------------------|
| 1. CANOPY ASSEMBLY | 4. LIGHT BAR |
| 2. SQUARE TUBE & THREADED ROD (QTY 2) | 5. 8.75"W x 5.75"H GLASS (QTY 12) |
| 3. ROD COMPONENTS | 6. 5.5"W x 5.75"H GLASS (QTY 12) |

Caution:

Fixture is OVERWEIGHT and not suitable for installation with standard Junction Box.
Be sure power is off at the main breaker box prior to installation.
Read all instructions in their entirety before beginning installation.

1. Carefully unpack all components and make certain that everything is accounted for.
2. Remove Hex and Acorn Nuts from Canopy Assembly to release Mounting Plate. Reserve Nuts for later use.
3. Affix Mounting Plate to ceiling ensuring connection is suitable to hold a minimum of 50lbs and that Electrical Supply Wires remain accessible. Do not mount Plate solely to Junction Box.
4. Feed Fixture Lead Wire through Threaded Rod and screw Rod into Coupling at top of Light Bar.
5. Screw other Threaded Rod into Coupling at opposite end of Light Bar.
6. Slide Square Tube over Wire and Threaded Rods.
7. Using Canopy Assembly Diagram for reference, assemble Rod Components on top of Square Tubes .
8. Set Canopy onto Square Tube assembly allowing Threaded Rods to protrude through. Secure with Spider Washers and Hex Nuts.
9. Following all Local Codes and Procedures, make electrical connection from Fixture Lead Wires to Supply Wires.
10. Lift Fixture up to ceiling allowing Mounting Plate Studs to protrude through Canopy. Secure with reserved Nuts.
11. Install 5.5"W Glass Panels between Sockets and at ends of Light Bar by removing Knurled Cap and sliding Panel onto Nipple ensuring that a Rubber Washers sandwich Panel. Use included Glass Diagram as reference.
12. Install 8.75"W Glass Panels by removing Knurled Cap and sliding Panel onto Nipple. Ensure that Rubber Washer is on either side of Panel. Use included Glass Diagram as reference.
13. Install 6 Medium Base 5Watt LED Bulbs(not included) into Sockets.
14. Power on and ENJOY!!!

